


XP6	Цепь	→
1	+100V	
2	+40V	
3	+15V	
4	+5V	
5	0В	
6	0В	
7	-15V	

XP7	Цепь	→
1	-15V	
2	0В	
4	Выход 1	
3	Выход 2	
6	+100V	
7	+15V	

XP8	Цепь	→
1	-15V	
2	+15V	
3	+40V	



XP1.6	Цепь	→
3	x 10	

