



AVR072: Accessing 16-bit I/O Registers

Features

- Routines for Accessing 16-bits I/O Registers
- Macros Included for AVR- and IAR Assembler


Description

All mid- and high-range AVR devices include a 16-bit Timer and some also include a 10-bit A/D Converter. These I/O modules have 16-bit registers that can be accessed from the AVR core using the *in* and *out* instructions. Since the AVR microcontroller has an 8-bit I/O bus the access to the I/O Register must be performed in two instruction cycles. An interrupt can occur between the instructions. If the interrupt function accesses the same resources (16-bit Timer or ADC) the 16-bit I/O Register access must be made an atomic operation, i.e., an operation that cannot be interrupted.

I/O modules with 16-bit Registers include a temporary register for the high byte (bit 15 to 8). Note that the 16-bit Timer (Timer1) has only one temporary register that is shared between all it's 16-bit register pairs. A 16-bit I/O read is normally done like this:

```
Cycle 1: in r16, TCNT1L ;Reading low byte into r16,this triggers the high
           ; byte to be latched in the temporary shadow
           ; register.
Cycle 2: in r17, TCNT1H ;Reading high byte from the temporary register.
```

Figure 1. 16-bit I/O Register Read⁽¹⁾



Note: 1. Circled numbers indicate cycle number.

If an interrupt occurs between the two instructions for any of the operations, and the interrupt handler access any of the Timer1's low bytes, the temporary register might change it's value. Returning from the interrupt the AVR core now reads the corrupted value into register r17.

8-bit AVR[®]
Microcontroller

Application
Note




A 16-bit I/O write is done as follow:

```

; r17 contains the high byte while r16 contains
; the low byte that is to be written.
Cycle 1: out TCNT1H, r17 ; Writing the high byte to the temporary register.
Cycle 2: out TCNT1L, r16 ; Writing both the low byte and the temporary
; register into the I/O Register.

```

Figure 2. 16-bit I/O Register Write⁽¹⁾



Note: 1. Circled numbers indicate cycle number.

Note that the read and the write operation differ in the order the high and low I/O Register is accessed. If the order is reversed, the high value will be incorrectly read or written.

Solution

To avoid the situations described above, the following macros for the AVR assembler and the IAR C compiler can be used

AVR Assembler Macros

```
.macro outw
    cli
    out    @0, @1
    out    @0-1, @2
    sei
.endmacro
```

```
.macro inw
    cli
    in     @1, @2-1
    in     @0, @2
    sei
.endmacro
```

Usage

```
.include "8515def.inc"
inw    r17, r16, TCNT1H    ; Reads the counter value (high, low, adr)
outw    TCNT1H, r17, r16    ; Writes the counter value (adr, high, low)
```

IAR C MACROS

```
#include <ina90.h>
```

```
#define outw( ADDRESS, VAL )\
{\
    _CLI();
    ADDRESS = VAL;\
    _SEI();\
}
```

```
#define inw( ADDRESS, VAL )\
{\
    _CLI();
    VAL = ADDRESS;\
    _SEI();\
}
```

Usage

```
#include <io8515.h>
```

```
inw( TCNT1, i )    /* Reads the counter value */
outw( TCNT1, i )    /* Writes the counter value */
```

Notes

- Notes:
1. The outw and the inw macros uses four instruction cycles which is the same amount of cycles as the ret instruction uses. Doing so the macros will not increase the worst case interrupt response time.
 2. The macros will not work for setting the EEPROM address since the address can not be changed during write operation. This will lead to corruption of the data written.



Atmel Headquarters

Corporate Headquarters

2325 Orchard Parkway
San Jose, CA 95131
TEL 1(408) 441-0311
FAX 1(408) 487-2600

Europe

Atmel Sarl
Route des Arsenaux 41
Case Postale 80
CH-1705 Fribourg
Switzerland
TEL (41) 26-426-5555
FAX (41) 26-426-5500

Asia

Room 1219
Chinachem Golden Plaza
77 Mody Road Tsimhatsui
East Kowloon
Hong Kong
TEL (852) 2721-9778
FAX (852) 2722-1369

Japan

9F, Tonetsu Shinkawa Bldg.
1-24-8 Shinkawa
Chuo-ku, Tokyo 104-0033
Japan
TEL (81) 3-3523-3551
FAX (81) 3-3523-7581

Atmel Operations

Memory

2325 Orchard Parkway
San Jose, CA 95131
TEL 1(408) 441-0311
FAX 1(408) 436-4314

Microcontrollers

2325 Orchard Parkway
San Jose, CA 95131
TEL 1(408) 441-0311
FAX 1(408) 436-4314

La Chantrerie
BP 70602
44306 Nantes Cedex 3, France
TEL (33) 2-40-18-18-18
FAX (33) 2-40-18-19-60

ASIC/ASSP/Smart Cards

Zone Industrielle
13106 Rousset Cedex, France
TEL (33) 4-42-53-60-00
FAX (33) 4-42-53-60-01

1150 East Cheyenne Mtn. Blvd.
Colorado Springs, CO 80906
TEL 1(719) 576-3300
FAX 1(719) 540-1759

Scottish Enterprise Technology Park
Maxwell Building
East Kilbride G75 0QR, Scotland
TEL (44) 1355-803-000
FAX (44) 1355-242-743

RF/Automotive

Theresienstrasse 2
Postfach 3535
74025 Heilbronn, Germany
TEL (49) 71-31-67-0
FAX (49) 71-31-67-2340

1150 East Cheyenne Mtn. Blvd.
Colorado Springs, CO 80906
TEL 1(719) 576-3300
FAX 1(719) 540-1759

Biometrics/Imaging/Hi-Rel MPU/ High Speed Converters/RF Datacom

Avenue de Rochepleine
BP 123
38521 Saint-Egreve Cedex, France
TEL (33) 4-76-58-30-00
FAX (33) 4-76-58-34-80

e-mail

literature@atmel.com

Web Site

<http://www.atmel.com>

© Atmel Corporation 2002.

Atmel Corporation makes no warranty for the use of its products, other than those expressly contained in the Company's standard warranty which is detailed in Atmel's Terms and Conditions located on the Company's web site. The Company assumes no responsibility for any errors which may appear in this document, reserves the right to change devices or specifications detailed herein at any time without notice, and does not make any commitment to update the information contained herein. No licenses to patents or other intellectual property of Atmel are granted by the Company in connection with the sale of Atmel products, expressly or by implication. Atmel's products are not authorized for use as critical components in life support devices or systems.

ATMEL® and AVR® are the registered trademarks of Atmel.

Other terms and product names may be the trademarks of others.



Printed on recycled paper.